

Taking Care of Product

Please take time to read and understand this brochure. This guidelines presented here can prevent costly repairs and/or replacement of product.



Baymont, Inc.

30 Red Bay Road
PO Box 18
Golden, MS 38838

Phone: 662 454 7993
Fax: 662 454 9850
Email: contact@baymontbath.com

Baymont, Inc.

CARE, HANDLING,
STORAGE AND
INSTALLATION OF
FIBERGLASS
CORNER TUB UNITS



Fiberglass Tubs and Showers

Handling for CT units

From Truck to Storage area

Corner units are shipped on a reusable rack. Unload truck with a forklift

Always use a two wheeler to move product that is designed for the task. (Will be supplied by Baymont). This unit incorporates a stabilizing board to maintain balance of product.

Storage to Plumbing

Units may be moved while still in the rack, or with the proper Baymont Supplied two wheeler.

Use a sawhorse to lean unit against in order to plumb. Do not lay on its back, sides or face.



To drill holes for faucets, do not use a spade bit, use a carbide-tipped hole saw to prevent chipping and damage.

Sizes can be found from Faucet Distributor.

Plumbing to install area

Line bottom and seat areas with carpet pad to prevent scratches and chips.

Always use two people to remove CT's from rack to prevent impact damage, scratching and chipping. Do not use a forklift for this task.

Do not cut braces for any reason. It is acceptable to drill braces.

Two people should always handle unit. Do not drag or shove unit across floor.

Storage

Do not lay units on face or side. Stand units upright on a level surface

It is highly recommended that covered storage be used to prevent damage and discoloration due to the elements.

Always rotate stock weekly. The longer a unit is in storage, it is more likely to sustain damage.


While units are in storage, do not use as a trash or storage receptacle.

Foreign bodies can cause scratching, cracking, and discoloration.



After a rack of Corner Tubs has been moved from receiving to the storage area, Always cut the plastic shipping band that is securing the top unit.

Installation



Always follow Installation instructions supplied with every unit. .

Always use a trim approved for use with fiberglass units. When installing the trim, entire nailing flange must be completely covered.

Legs must touch floor after unit is leveled and plumbed. The use of leg shims may be necessary, depending on the floor and wall condition.


When securing unit to wall, use 1/8" rubber shims along entire flange area to prevent spider cracks.

Spot fasten the unit flanges while constantly insuring the unit remains level. Fasten according to drawing.

Always pre-drill holes in flange before attaching to backer board or stud.

Always use a driver that has adjustable torque when attaching flange to wall to prevent flange damage. Baymont recommends the DeWalt model DW983 set to torque adjustment 11.

Use carpet pad or other suitable fixture, on tub bottoms and seat areas to prevent scratching and damage from foreign bodies on shoes.



Following Installation, no objects should be stored or placed in unit. Leave carpet padding in unit until last possible moment.

Do not use abrasive cleansers or chemicals such as gas, mineral spirits, etc. to clean units. Use of unap-

Tools Required

- 4 FT Level
- Leveling shims
- Hole Saws
- 3/16" drill bit
- 1/8" Rubber shims

Baymont, Inc.

30 Red Bay Road
PO Box 18
Golden, MS 38838

Phone: 662 454 7993

Fax: 662 454 9850

Email: contact@baymontbath.com